

TIPS & TRICKS

So, you downloaded our bikefit form, huh... Cool!

Before you and the bikefitter get started, there are some tips we want to give you:

1. Make a bikefit where your saddle is nicely centered on the seat post. If you make a bikefit where your saddle is more towards the front or the back, it will be the same on your new Corsa.
2. We like 110mm stems. It has a nice length, excellent handling. We're a fan. So, same rules here, remember that the stem you use during the bikefit, will be the stem you will need to use on your Corsa.

BIKEFIT DATA WE NEED TO BUILD YOUR BIKE

TO BE FILLED IN	Head Tube Length (in mm)
	Head Tube Angle
	Top Tube Length (Horizontal; in mm)
	Seat Tube Length (Center Top; in mm)
	Seat Tube Angle
	Drop (in mm)
	Chain Stay Length (in mm)

NOTES TO THE ENGINEER

BIKEFIT DATA WE WILL SEND BACK FOR YOU TO CONFIRM

WILL BE FILLED IN BY OUR ENGINEER	Stack (in mm)	Stack and Reach will tell you everything about the way you will sit on your bike. These numbers are the ideal way to compare with your regular bike.
	Reach (in mm)	
	Front - Center (in mm)	Tells you the foot clearance.
	Trail (in mm)	The shorter, the more aggressive your bike will steer.
	Wheelbase (in mm)	The longer your wheelbase, the more confidence it will give, but it will handle less aggressive as well.

REMARKS FROM THE ENGINEER